

BlueStone

Hướng dẫn sử dụng Ấm đun nước



Áp dụng cho model:

KTB-3439

KTB-3417

KTB-3415



Hãy giữ lại Hướng Dẫn Sử Dụng vì sự an toàn của bạn.

CE CB

- Các sản phẩm và các linh kiện sản phẩm BlueStone đều được sản xuất dựa trên quy trình chuyên nghiệp theo tiêu chuẩn Châu Âu CE (The European Conformity), tiêu chuẩn CB đạt yêu cầu về chất lượng và an toàn sản phẩm.
- Bên cạnh đó, các sản phẩm BlueStone đều được kiểm tra chặt chẽ về mẫu mã, dây chuyền sản xuất và kiểm định lô hàng.
- Sản phẩm BlueStone được công ty đối tác Mỹ Great American Appliance (GAA Corp) tư vấn về quản lý và quy trình. GAA là công ty được thành lập và hoạt động theo luật pháp Mỹ theo Giấy chứng nhận thành lập số 3089043 do văn phòng thư ký bang California cấp có trụ sở chính tại 7809 Michigan Ave Oakland, CA 94605, Hoa Kỳ.
- Sản phẩm BlueStone được thiết kế theo kiểu dáng công nghiệp với màu sắc đa dạng. Dưới sự nghiên cứu và thiết kế của các chuyên viên thiết kế và kỹ thuật viên chuyên nghiệp, các sản phẩm BlueStone được thiết kế theo tiêu chuẩn quốc tế nghiêm ngặt nhằm đáp ứng được nhu cầu ngày càng cao của người tiêu dùng.
- BlueStone luôn coi trọng việc chăm sóc khách hàng. Các sản phẩm BlueStone đều được bảo hành 2 năm.

MỤC LỤC:

THÔNG SỐ KỸ THUẬT	4
CẤU TẠO SẢN PHẨM	4
HƯỚNG DẪN SỬ DỤNG	5
SỬ DỤNG LẦN ĐẦU	6
TRƯỚC KHI SỬ DỤNG ẤM	7
CÁCH SỬ DỤNG ẤM	7
CÁCH LAU CHÙI VÀ GIỮ GÌN ẤM	7
CHUNG TAY BẢO VỆ MÔI TRƯỜNG	8

CONTENTS:

TECHNOLOGY PARAMETER	11
GENERAL DESCRIPTION	11
INSTRUCTION FOR USE	12
FIRST TIME USING	13
PREPARE FOR USING	14
USING THE APPLIANCE	14
CARING AND CLEANING	15
ENVIRONMENT FRIENDLY DISPOSAL	15

- Tiêu chuẩn kỹ thuật nhà sản xuất có thể thay đổi mà không cần báo trước.
- Manufacturer has right to replace technical standard or specification without any notice.

THÔNG SỐ KỸ THUẬT

Model	Nguồn điện	Công suất	Dung tích	Chứng nhận
KTB-3439	220-240V~50/60Hz	1850-2200W	1700ml	CE, CB
KTB-3417	220-240V~50/60Hz	1850-2200W	1700ml	CB
KTB-3415	220-240V~50/60Hz	1850-2200W	1000ml	CB

CẤU TẠO SẢN PHẨM

KTB-3439/ 3417/ 3415

1. Miệng bình
2. Thân bình
3. Chỉ báo mực nước
4. Đế nguồn
5. Công tắc nguồn
6. Tay cầm
7. Nút nhấn mở nắp
8. Nắp bình



KTB-3439



KTB-3415



KTB-3417

HƯỚNG DẪN SỬ DỤNG

CHÚ Ý

Vui lòng đọc kỹ hướng dẫn sử dụng trước khi kết nối ấm đun nước với nguồn điện để tránh ảnh hưởng đến sản phẩm do sử dụng không đúng cách.

- 1 Vận hành không đúng cách có thể gây hư hỏng cho thiết bị và ảnh hưởng đến người sử dụng.
- 2 Tháo phích cắm ra khỏi ổ điện khi không sử dụng.
- 3 Luôn đặt ấm đun ở những nơi khô ráo.
- 4 Không để dây điện hoặc phích cắm tiếp xúc với nước hoặc chất lỏng khác. Nếu điều này xảy ra, rút phích cắm ngay lập tức và sau đó nhờ nhân viên kỹ thuật kiểm tra trước khi sử dụng lại.
- 5 Không sử dụng ấm nếu dây điện hoặc phích cắm có dấu hiệu bị hư hỏng.
- 6 Nếu ấm hoặc đế ấm bị rơi, va đập mạnh nên đem ngay đến trạm bảo hành để nhân viên kỹ thuật kiểm tra và sửa chữa (nếu cần).
- 7 Phải đảm bảo dây nguồn không treo trên các cạnh sắc nhọn và không để ấm gần các thiết bị phát (tỏa) nhiệt khác.
- 8 Chỉ nắm đầu phích điện để rút ra khỏi ổ cắm, không được nắm dây điện mà giật vì có thể gây hư hỏng dây điện và nguy hiểm cho người sử dụng.
- 9 Sau khi rút phích cắm, phần tử gia nhiệt vẫn còn nóng nên không được chạm vào hoặc đặt lên các bề mặt dễ cháy.
- 10 Nếu đổ nước vào ấm quá đầy, nước sôi có thể trào ra ngoài gây nguy hiểm.
- 11 Đặt ấm ở nơi bằng phẳng, tránh xa vật phát nhiệt. Không đặt phía dưới màn cửa, tủ đựng thức ăn.

- 12 Chú ý quan sát ấm trong suốt quá trình nấu.
- 13 Để xa tầm tay trẻ em. Người thiếu năng, trẻ em không được tự ý sử dụng thiết bị khi không có sự hướng dẫn và giám sát.
- 14 Ấm điện chỉ sử dụng với đế cung cấp kèm theo. Để ấm chỉ dùng với thân ấm để đun nước không sử dụng chân đế này cho bất kỳ mục đích nào khác.
- 15 Không được di chuyển ấm khỏi chân đế trong khi đun. Chỉ di chuyển khi đã ngắt điện hoàn toàn.
- 16 Phải đậy chặt nắp ấm trước khi cắm điện. Nếu nắp không được đậy chặt, sau khi nấu sôi, nước nóng có thể trào ra ngoài gây nguy hiểm cho người dùng.
- 17 Ấm nước chỉ dùng để đun nước. Không sử dụng để đun bất kỳ loại chất lỏng nào khác.
- 18 Ấm được thiết kế chỉ để dùng cho gia đình.
- 19 Không được ngâm sản phẩm trong nước.
- 20 Không được tự ý thay thế dây dẫn điện khi bị hỏng. Đem ngay đến trung tâm bảo hành để được thay thế nhằm tránh xảy ra sự cố.
- 21 Không mở nắp khi nước đang sôi.
- 22 Ngắt điện trước khi lấy ấm ra khỏi đế ấm.
- 23 Không vận hành thiết bị khi không có nước trong ấm.
- 24 Trẻ em cần được giám sát để đảm bảo không nghịch thiết bị.

SỬ DỤNG LẦN ĐẦU

- 1 Lấy ấm và các phụ kiện đi kèm (nếu có) ra khỏi hộp.
- 2 Trước khi cắm điện, hãy kiểm tra điện thế ghi trên ấm có phù hợp với điện thế nguồn tại nhà bạn không.
- 3 Đổ nước vào ấm đến điểm **1.7L** với model KTB-3439/3437 và **1L** với model KTB-3415. Sau khi nước sôi, ngắt điện và đổ nước đi, sau đó đun lại lần 2 để sử dụng.

TRƯỚC KHI SỬ DỤNG

MỞ NẮP

ĐỔ NƯỚC

- 1 Lấy ấm khỏi chân đế.
- 2 Bạn có thể đổ nước thông qua vòi ấm hoặc mở nắp bằng cách nhấn nút mở trên nắp ấm hoặc trên tay cầm.
- 3 Không nên đổ ít nước dưới điểm "**0.5L**".
- 4 Không đổ quá đầy nước (Nghĩa là không qua điểm **1.7L** với model KTB-3439/3437 và **1L** với model KTB-3415) để không bị tràn trong quá trình nấu

CÁCH SỬ DỤNG ẤM

BẬT CÔNG TẮC

- 1 Sau khi đổ nước vào ấm, đặt ấm nước lên chân đế.
- 2 Cắm phích điện vào nguồn điện và bật nút "ON/OFF". Ấm sẽ bắt đầu vận hành và đèn tín hiệu sẽ sáng.

TẮT CÔNG TẮC

Khi nước sôi, ấm sẽ tự động ngắt điện và đèn tín hiệu sẽ tắt theo.

LƯU Ý:

Thiết bị có một hệ thống an toàn. Nếu như ấm không có nước hay cạn nước do người sử dụng sơ suất. Ấm sẽ tự động ngắt. Trong trường hợp này, hãy để ấm nguội hoàn toàn trước khi đổ nước nấu lại.

BẬT CÔNG TẮT TRỞ LẠI

Để nguội ấm khoảng 30-60 giây trước khi khởi động lại ấm đun.

CÁCH LAU CHÙI VÀ GIỮ GÌN ẤM

- 1 Tháo phích cắm khỏi ổ điện và để ấm nguội hoàn toàn.
- 2 Dùng vải mềm, ẩm để lau chùi vỏ ấm và chân đế. Sau đó lau lại bằng vải khô, không nên dùng chất tẩy rửa để vệ sinh ấm.
- 3 Để làm sạch bên trong ấm, liên quan đến các chi tiết kỹ thuật. Hãy nhờ nhân viên kỹ thuật giúp đỡ.

LƯỚI LỌC

- 1 Lấy lưới lọc ra khỏi ấm nước.
- 2 Đặt lưới lọc dưới vòi nước và lau nhẹ những bụi, mảng bám bằng chổi mềm. (không bán kèm chổi mềm)
- 3 Đặt lại lưới lọc vào giữa 2 rãnh gắn miệng vòi ở phía trước ấm.

BẢO QUẢN

Quấn dây điện vòng quanh chân đế sau khi sử dụng, vì đã có bộ phận lưu trữ dây dưới chân đế.

CHÚ Ý

Không được tự ý chỉnh sửa sản phẩm.
Hãy liên lạc với trung tâm dịch vụ bảo hành để sửa chữa.

CHUNG TAY BẢO VỆ MÔI TRƯỜNG

Hãy tuân thủ những quy định bảo vệ môi trường của địa phương: đem những thiết bị điện không còn sử dụng đến trung tâm xử lý chất thải phù hợp.

BlueStone

User manual

Kettle



Apply for model:

KTB-3439

KTB-3417

KTB-3415



Always keep manual for your safety

CE CB

● Standard Compliance

BlueStone products are manufactured under the Standards and the technical rules for product safety design and testing. BlueStone products and associated accessories intended for professional, industrial-process under CE (The European Conformity), CB Standards and have been successfully tested on areas: sampling test, assembling test and lot test.

● Trademark

BlueStone manufactured products are based on the consultation by Great American Appliance (GAA Corp) a company incorporated and existing under the laws of United States of America under Certificate of Incorporation No. 3089043 in the secretary office located in the state of California in Michigan, Ave Oakland, CA 94605, USA.

● Industrial design

BlueStone provides products with industrial design and color variations offering a broad range of possibilities for customers. Through the experienced designers and technicians, BlueStone design has highly reliable solutions so the customers are assured of quality designed systems that meet stringent industry and international compliance regulations.

● After sales service

After sales service is considered by BlueStone as a major concern for our customers. With such, we provide our BlueStone products with a 2 years guaranteed warranty that help our end user feel at ease.

TECHNOLOGY PARAMETER

Model	Voltage	Power	Capacity	Chứng nhận
KTB-3439	220-240V~50/60Hz	1850-2200W	1700ml	CE, CB
KTB-3417	220-240V~50/60Hz	1850-2200W	1700ml	CB
KTB-3415	220-240V~50/60Hz	1850-2200W	1000ml	CB

GENERAL DESCRIPTION

KTB-3439/ 3417/ 3415

1. Spout
2. Body
3. Water level gauge
4. Power base
5. On/Off switch indicator lamp
6. Handle
7. Unlocking button for the lid
8. Lid



KTB-3439



KTB-3417



KTB-3415

INSTRUCTION FOR USE

SAFETY NOTICE

Please read these operating instructions through carefully before connecting your kettle to the power supply. In order to avoid damage due to incorrect use.

- 1 Incorrect operation and improper handling can lead to faults on the appliance and injuries to the user.
- 2 Unplug the appliance from power supply when not in use.
- 3 Keep the base unit away from damp and protect from splashes.
- 4 Do not immerse the unit cord or plug in water or other liquids. If it occurs, remove the plug immediately and then have the unit checked by an expert before using it again.
- 5 Do not operate the appliance if the cord or plug shows signs of damage.
- 6 If the appliance has fallen on the floor or has been cases take the appliance to a specialist for checking and repair if necessary.
- 7 Ensure that the cord does not hang over sharp edges and keep it away from hot surfaces.
- 8 Only pull it out of the power supply by the plug, not by the cord.
- 9 After pull the plug out, do not touch or put it on flammable surface because heating element still warm.
- 10 Do not fill water into the kettle too full because when boiling water will out flow.
- 11 Place the appliance on a stable surface, away from hot objects (e.g. hotplates), naked flames; do not place under curtains or low wall-cupboards.
- 12 You should never leave the appliance unattended during use.
- 13 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities,

or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- 14 Use the kettle only with the base unit supplied, and do not use the base unit for any other purposes.
- 15 Never remove the kettle from its base unit while in operation. Switch the appliance off first.
- 16 Close the lid properly before switching on. Otherwise, the appliance will not switch off automatically and hot water may overflow.
- 17 The kettle is used for heating water only and is not to be used for any other liquids.
- 18 The appliance is designed for household use only.
- 19 Do not immerse appliance in the water.
- 20 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 21 Do not open the lid when water boiling.
- 22 Unplug when take the kettle out of base.
- 23 Don't operate the appliance if no have water in the kettle.
- 24 Children should be supervised to ensure that do not play with the appliance.

FIRST TIME USING

- 1 Remove all packing materials from the kettle.
- 2 Before connecting of the kettle, check that voltage indicated on the rating label corresponds the mains voltage in your home.
- 3 Fill the kettle with cool water up to the "1.7L or 1L" mark and boil it. Empty the kettle. The appliance is ready for use.

PREPARE FOR USING

OPEN LID

FILLING

- 1 Remove the kettle from the base unit.
- 2 You can fill the kettle with water by opening the lid, by pressing on the lid release button.
- 3 Not recommend to fill with less than "0.5L", kettle is dry while operatin.
- 4 Do not fill water over the **1.7L** for model KTB-3439/3437 and **1L** for model KTB-3415

USING THE APPLIANCE

SWITCHING ON

- 1 After filling your kettle with water, place the kettle on the base unit.
- 2 Connect plug to power supply and pull down the On/Off switch. The appliance will begin to operate and the indicator light will come on.

SWITCHING OFF

When the water boils, the kettle will switch off automatically and the indicator light will go off.

NOTE:

This appliance has a safety system, which automatically switches off the heater element if the appliance is inadvertently switched when empty, or if it boils dry. In this case, let the appliance cool down completely, before filling with water again.

SWITCHING ON AGAIN

The kettle can be switched on again after cooling down about 30-60 seconds, while the kettle has been switched off automatically.

CARING AND CLEANING

- 1 Always remove the plug from the power supply and let the appliance cool down completely.
- 2 Clean the outside of the kettle and the base unit with a soft damp cloth. Then wipe with a dry cloth. Do not use scouring.
- 3 Descale at regular intervals. Uses a descaling agent, which can be obtained from specialist shops and follow the instructions given.

THE FILTER

- 1 Remove the filter from the kettle.
- 2 Place the filter under the tap and clean dust and plaque with a soft brush.
- 3 Place the filter in the middle of the two grooves near the spout in the front of the kettle.

STORAGE

The cord could be winded into the base unit that has a cord storage compartment.

NOTE

Do not try to adjust or repair this appliance by yourself. Please contact with a qualified technician or after sales service center for repair.

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipments to appropriate waste disposal center.

