

BlueStone

Model
KTB-3425

Hướng dẫn sử dụng Ấm đun siêu tốc



Tấm nhiệt phẳng và thân ấm bằng thép không gỉ 304 giúp đun sôi nhanh, an toàn cho sức khỏe

Bộ điều khiển Strix của Anh với độ bền cao giúp kiểm soát nhiệt, an toàn khi sử dụng

Tự động ngắt điện khi sôi và khi ấm can nước, an toàn khi sử dụng



Hãy giữ lại Hướng Dẫn Sử Dụng vì sự an toàn của bạn.



CB RoHS

- Các sản phẩm và các linh kiện sản phẩm BlueStone đều được sản xuất dựa trên quy trình chuyên nghiệp theo tiêu chuẩn RoHS (Restriction of Hazardous Substances), tiêu chuẩn của Đức GS (Geprüfte Sicherheit), tiêu chuẩn CB về chất lượng và an toàn sản phẩm. Bên cạnh đó, các sản phẩm BlueStone đều được kiểm tra chặt chẽ về mẫu mã, dây chuyền sản xuất và kiểm định lô hàng.
- Sản phẩm BlueStone được công ty đối tác Mỹ Great American Appliance (GAA Corp) tư vấn về quản lý và quy trình. GAA là công ty được thành lập và hoạt động theo luật pháp Mỹ theo Giấy chứng nhận thành lập số 3089043 do văn phòng thư ký bang California cấp có trụ sở chính tại 7809 Michigan Ave Oakland, CA 94605, Hoa Kỳ.
- Sản phẩm BlueStone được thiết kế theo kiểu dáng công nghiệp với màu sắc đa dạng. Dưới sự nghiên cứu và thiết kế của các chuyên viên thiết kế và kỹ thuật viên chuyên nghiệp, các sản phẩm BlueStone được thiết kế theo tiêu chuẩn quốc tế nghiêm ngặt nhằm đáp ứng được nhu cầu ngày càng cao của người tiêu dùng.
- BlueStone luôn coi trọng việc chăm sóc khách hàng. Các sản phẩm BlueStone đều được bảo hành 2 năm

MỤC LỤC

THÔNG SỐ KỸ THUẬT	04
HƯỚNG DẪN SỬ DỤNG	05
TRƯỚC KHI SỬ DỤNG	07
CÁCH SỬ DỤNG ẤM	07
CÁCH LAU CHÙI VÀ GIỮ GÌN ẤM	08
CHUNG TAY BẢO VỆ MÔI TRƯỜNG	08

CONTENTS

GENERAL DESCRIPTION	11
INSTRUCTION FOR USE	12
PREPARE FOR USING	14
USING THE APPLIANCE	14
CARE AND CLEANING	15
ENVIRONMENT FRIENDLY DISPOSAL	15

- Tiêu chuẩn kỹ thuật nhà sản xuất có thể thay đổi mà không cần báo trước.
- Manufacturer has right to replace technical standard or specification without any notice.

THÔNG SỐ KỸ THUẬT

Model: KTB-3425

Nguồn điện: 220-240V~50/60Hz

Công suất: 1850-2200W

Dung tích: 1.7L

Chúng nhận: CB, GS, RoHS

1.	Vòi ảm	5.	Tay cầm
2.	Đế ảm	6.	Bảng hiện thị mức nước
3.	Nắp ảm	7.	Nút tắt /mở nguồn
4.	Nút mở nắp ảm		



HƯỚNG DẪN SỬ DỤNG

CHÚ Ý AN TOÀN:

Vui lòng đọc hướng dẫn sử dụng thật kỹ trước khi kết nối ảm đun nước với nguồn điện để tránh thiệt hại do sử dụng không đúng.

- 1 Vận hành không đúng có thể dẫn tới lỗi cho thiết bị và gây ảnh hưởng cho người sử dụng.
- 2 Tháo phích cắm khỏi ổ điện khi không sử dụng.
- 3 Luôn giữ ảm đun ở những nơi khô ráo.
- 4 Không để dây điện hoặc phích cắm tiếp xúc với nước hoặc chất lỏng khác. Nếu điều này xảy ra, phải di chuyển phích cắm ngay lập tức và sau đó nhờ nhân viên kỹ thuật kiểm tra trước khi sử dụng lại.
- 5 Không sử dụng ảm nếu dây điện hoặc phích cắm có dấu hiệu bị hư hỏng.
- 6 Nếu ảm hoặc đế ảm bị rơi, va đập mạnh. Hãy đem ảm đến trạm bảo hành để nhân viên kỹ thuật kiểm tra (nếu cần thiết).
- 7 Phải đảm bảo dây nguồn không treo trên các cạnh sắc nhọn và không để ảm gần các thiết bị phát (tỏa) nhiệt khác.
- 8 Luôn tháo phích cắm khỏi ổ điện khi không sử dụng, vui lòng nắm đầu phích điện để rút ra khỏi ổ cắm điện, không nắm dây điện mà giật để khỏi hư dây điện.
- 9 Sau khi rút phích cắm, phần tử gia nhiệt vẫn còn nóng nên không được chạm vào hoặc đặt lên các bề mặt dễ cháy.
- 10 Nếu đổ nước vào ảm quá đầy, nước sôi có thể trào ra ngoài gây nguy hiểm.
- 11 Đặt ảm ở nơi bằng phẳng, tránh xa vật phát nhiệt. Không đặt phía dưới màn cửa, tủ đựng thức ăn.
- 12 Nên chú ý đến ảm trong khi đun.
- 13 Không để trẻ em sử dụng ảm khi không có sự giám sát của người lớn.

- 14 Ấm điện chỉ sử dụng với đế cung cấp kèm theo. Để ấm chỉ dùng với thân ấm để đun nước, không sử dụng chân đế này cho bất kỳ mục đích nào khác.
- 15 Không được di chuyển ấm khỏi chân đế trong khi đun. Chỉ di chuyển khi đã ngắt điện hoàn toàn.
- 16 Chú ý đậy nắp chặt trước khi cắm điện. Nếu không thì ấm sẽ không tự động tắt khi nước sôi và nước nóng có thể tràn ra ngoài.
- 17 Ấm nước chỉ dùng để đun nước. Không sử dụng để đun bất kỳ loại chất lỏng nào khác.
- 18 Ấm được thiết kế chỉ để dùng cho gia đình.
- 19 Không được ngâm thiết bị trong nước.
- 20 Nếu dây dẫn nguồn bị hỏng thì phải do nhà chế tạo hoặc đại lý dịch vụ hoặc những người có trình độ tương đương thay thế nhằm tránh xảy ra sự cố.
- 21 Không mở nắp khi nước đang sôi.
- 22 Ngắt điện trước khi lấy ấm ra khỏi đế ấm.
- 23 Không vận hành khi không có nước trong ấm.
- 24 Thiết bị này không thích hợp cho người tàn tật, thiếu năng trí tuệ, hoặc những người không có kinh nghiệm và thiếu hiểu biết (kể cả trẻ em), trừ khi được giám sát hoặc hướng dẫn sử dụng thiết bị bởi người có trách nhiệm về sự an toàn của họ.

SỬ DỤNG LẦN ĐẦU

- 1 Lấy ấm ra khỏi hộp, lấy tất cả các vật liệu (nếu có) ra khỏi ấm.
- 2 Trước khi cắm điện, hãy kiểm tra điện thế ghi trên ấm có phù hợp với điện thế nguồn tại nhà bạn không.
- 3 Đổ nước vào ấm đến điểm "Max" và đun nước. Sau khi nước sôi, ngắt điện và đổ nước đi, sau đó đun lại lần 2 để sử dụng.

TRƯỚC KHI SỬ DỤNG

PHỄU LỌC

- 1 Mở nắp bằng cách nhấn vào nút mở trên nắp.
- 2 Đặt bộ lọc giữa hai rãnh gần vòi ấm ở phía trước ấm.
- 3 Đảm bảo phễu lọc được gắn chặt ở phần cuối của rãnh và vừa khít sau khi đóng nắp.

LƯU Ý:

Phải giữ chặt phễu lọc trong ấm nước khi nấu. Không lấy phễu ra khi trong ấm có nước nóng, chỉ lấy ra khi nước đã nguội hoàn toàn.

ĐỔ NƯỚC

- 1 Lấy ấm khỏi chân đế.
- 2 Bạn có thể đổ nước thông qua vòi ấm hoặc mở nắp bằng cách nhấn nút mở trên nắp ấm.
- 3 Không nên đổ ít nước dưới điểm "Min" để tránh ấm bị khô trong khi đun.
- 4 Không đổ quá đầy nước để không bị tràn trong thời gian nấu. Không đổ đầy hơn 1.7 lít nước (nghĩa là không qua điểm "MAX").

CÁCH SỬ DỤNG ẤM

MỞ CÔNG TẮC

- 1 Sau khi đổ nước vào ấm, đặt ấm nước lên chân đế.
- 2 Cắm điện vào nguồn điện và bật nút tắt/mở trên thân ấm. Ấm sẽ bắt đầu vận hành và đèn tín hiệu sẽ sáng.

TẮT CÔNG TẮC

Khi nước sôi, ấm nước sẽ tự động tắt và đèn tín hiệu cũng tắt theo.

LƯU Ý:

Thiết bị có một hệ thống an toàn. Nếu như ấm không có nước hay cạn nước do người sử dụng sơ suất. Ấm sẽ tự động ngắt. Trong trường hợp này, hãy để ấm nguội hoàn toàn trước khi đổ nước nấu lại.

MỞ CÔNG TẮC TRỞ LẠI

Có thể sử dụng lại ấm đun nước sau khi để nguội khoảng 15-20 giây.

CÁCH LAU CHÙI VÀ GIỮ GÌN ẤM

- 1 Tháo phích cắm khỏi ổ điện và để ấm nguội hoàn toàn.
- 2 Lau chùi vỏ ấm và chân đế với vải hơi ẩm, sau đó lau lại bằng vải khô. Không nên dùng chất tẩy rửa.
- 3 Để làm sạch bên trong ấm, liên quan đến các chi tiết kỹ thuật. Hãy nhờ nhân viên kỹ thuật giúp đỡ.

BẢO QUẢN

Quấn dây điện vòng quanh chân đế, có bộ phận lưu trữ dây dưới chân đế.

CHÚ Ý

- 1 Nếu bạn không giải quyết sự cố bằng các giải pháp trên hãy liên lạc với trung tâm dịch vụ bảo hành để sửa chữa.
- 2 Không được tự ý chỉnh sửa sản phẩm.

CHUNG TAY BẢO VỆ MÔI TRƯỜNG

Hãy tuân thủ những quy định bảo vệ môi trường của địa phương: đem những thiết bị điện không còn sử dụng đến trung tâm xử lý chất thải phù hợp.

BlueStone

Model
KTB-3425

User manual Kettle



Flat and stainless steel 304 concealed heating element, fast boiling, good for health

British Strix control, high durability, temperature control, safe usage

Automatic shut off & boil dry protector, safe usage



Always keep manual for your safety



CB RoHS

• Standard Compliance

BlueStone products are manufactured under the Standards and the technical rules for product safety design and testing.

BlueStone products and associated accessories intended for professional, industrial-process under RoHS (Restriction of Hazardous Substances), GS (Geprüfte Sicherheit), CB Standards and have been successfully tested on areas: sampling test, assembling test and lot test.

• Trademark

BlueStone manufactured products are based on the consultation by Great American Appliance (GAA Corp) a company incorporated and existing under the laws of United States of America under Certificate of Incorporation No. 3089043 in the secretary office located in the state of California in Michigan, Ave Oakland, CA 94605, USA.

• Industrial design

BlueStone provides products with industrial design and color variations offering a broad range of possibilities for customers. Through the experienced designers and technicians, BlueStone design has highly reliable solutions so the customers are assured of quality designed systems that meet stringent industry and international compliance regulations.

• After sales service

After sales service is considered by BlueStone as a major concern for our customers. With such, we provide our BlueStone products with a 2 years guaranteed warranty that help our end user feel at ease.

GENERAL DESCRIPTION

Model: KTB-3425

Voltage: 220-240V~50/60Hz

Power: 1850-2200W

Capacity: 1.7L

Certificate: CB, GS, RoHS

1.	Spout	5.	Handle
2.	Base station	6.	Water level
3.	Lid	7.	On/Off switch with indicator light
4.	Unlocking for the lid		



INSTRUCTION FOR USE

SAFETY NOTICE

Please read these operating instructions through carefully before connecting your kettle to the power supply, in order to avoid damage due to incorrect use.

- 1 Incorrect operation and improper handling can lead to faults on the appliance and injuries to the user.
- 2 Unplug the appliance from power supply when not in use.
- 3 Keep the base unit away from damp and protect from splashes.
- 4 Do not immerse the unit cord or plug in water or other liquids. If this should occur, remove the plug immediately and then have the unit checked by an expert before using it again.
- 5 Do not operate the appliance if the cord or plug shows signs of damage.
- 6 If the appliance has fallen on the floor or has been cases take the appliance to a specialist for checking and repair if necessary.
- 7 Ensure that the cord does not hang over sharp edges and keep it away from hot surfaces.
- 8 Only pull it out of the power supply by the plug, not by the cord.
- 9 After pull the plug out, do not touch or put it on flammable surface because heating element still warm.
- 10 Do not fill water into the kettle too full because when boiling water will out flow.
- 11 Place the appliance on a stable surface, away from hot objects (e.g. hotplates), naked flames; do not place under curtains or low wall-cupboards.
- 12 You should never leave the appliance unattended during use.
- 13 Children should never use electrical domestic appliances unsupervised.

- 14 Use the kettle only with the base unit supplied, and do not use the base unit for any other purposes.
- 15 Never remove the kettle from its base unit while in operation. Switch the appliance off first.
- 16 Take care to close the lid properly before switching on. Otherwise, the appliance will not switch off automatically and hot water may overflow.
- 17 The kettle is used for heating water only and is not to be used for any other liquids.
- 18 The appliance is designed for household use only.
- 19 Do not immerse appliance in the water.
- 20 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 21 Do not open the lid when water boiling.
- 22 Unplug when take the kettle out of base.
- 23 Don't operate the appliance if no have water in the kette.
- 24 The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

FIRST TIME USING

- 1 Remove all packing materials from the kettle.
- 2 Before connecting of the kettle check, that voltage indicated on the rating label corresponds the mains voltage in your home.
- 3 Fill the kettle with cool water up to the "MAX" mark and boil it. After boiled water, switch off and empty the kettle. Then the appliance is ready for use.

PREPARE FOR USING

FILTER PLAGGING

- 1 Open the lid by pressing on the lid release button.
- 2 Place the filter between the two grooves near the spout at the front of the kettle.
- 3 Ensure that the filter is pressed down to the bottom of the grooves and fits correctly then close the lid.

NOTE:

Never leave the filter loose in the kettle. Never remove the filter while the kettle contains hot water.

FILLING

- 1 Remove the kettle from the base unit.
- 2 You can fill the kettle with water by opening the lid, by pressing on the lid release button.
- 3 Not recommend to fill water with less than level "MIN", kettle is dry while operating.
- 4 Do not fill water with more than 1.7 liters (up to "MAX" mark).

USING THE APPLIANCE

SWITCH ON

- 1 After filling your kettle with water, place the kettle on the base unit.
- 2 Connect plug to power supply and pull down the On/ Off switch.
- 3 The appliance will begin to operate and the indicator light will come on.

SWITCH OFF

When the water boils, the kettle will switch off automatically and the indicator light will go off.

NOTE:

This appliance has a safety system, which automatically switches off the heater element if the appliance is inadvertently switched when empty, or if it boils dry. In this case, let the appliance cool down completely, before filling with water again.

SWITCH ON AGAIN

The kettle can be switched on again after cooling down about 15-20 seconds, while the kettle has been switched off automatically.

CARE AND CLEANING

- 1 Always remove the plug from the power supply and let the appliance cool down completely.
- 2 Clean the outside of the kettle and the base unit with a soft damp cloth. Then wipe with a dry cloth. Do not use scouring
- 3 Decaled at regular intervals. Uses a decaling agent, which can be obtained from specialist shops and follow the instructions given.

STORAGE

The cord could be winded into the base unit that has a cord storage compartment.

NOTE

- 1 If you can not solve the problem, please contact with a qualified technician or after sales service center for repair.
- 2 Do not try to adjust or repair this appliance by yourself.

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment!
Please remember to respect the local regulations: hand in the non-working electrical equipments to appropriate waste disposal center.