

BlueStone

Hướng dẫn sử dụng Bếp từ



Áp dụng cho các model:

ICB-6628

ICB-6635



Hãy giữ lại Hướng Dẫn Sử Dụng vì sự an toàn của bạn.

CB

- Các sản phẩm và các linh kiện sản phẩm BlueStone đều được sản xuất dựa trên quy trình chuyên nghiệp theo tiêu chuẩn Châu Âu CE (The European Conformity), EMC (Electromagnetic Compatibility), tiêu chuẩn của Đức GS (Geprüfte Sicherheit), CB về chất lượng và an toàn sản phẩm.
- Bên cạnh đó, các sản phẩm BlueStone đều được kiểm tra chặt chẽ về mẫu mã, dây chuyền sản xuất và kiểm định lô hàng.
- Sản phẩm BlueStone được công ty đối tác Mỹ Great American Appliance (GAA Corp) tư vấn về quản lý và quy trình. GAA là công ty được thành lập và hoạt động theo luật pháp Mỹ theo Giấy chứng nhận thành lập số 3089043 do văn phòng thư ký bang California cấp có trụ sở chính tại 7809 Michigan Ave Oakland, CA 94605, Hoa Kỳ.
- Sản phẩm BlueStone được thiết kế theo kiểu dáng công nghiệp với màu sắc đa dạng. Dưới sự nghiên cứu và thiết kế của các chuyên viên thiết kế và kỹ thuật viên chuyên nghiệp, các sản phẩm Blue-Stone được thiết kế theo tiêu chuẩn quốc tế nghiêm ngặt nhằm đáp ứng được nhu cầu ngày càng cao của người tiêu dùng.
- BlueStone luôn coi trọng việc chăm sóc khách hàng. Các sản phẩm BlueStone đều được bảo hành 2 năm.

MỤC LỤC

CẢNH BÁO AN TOÀN	04
ĐẶC TÍNH KỸ THUẬT	05
MÔ TẢ TỔNG QUÁT	06
HƯỚNG DẪN SỬ DỤNG	07
CÁC LOẠI NỒI PHÙ HỢP	10
CÁCH VỆ SINH VÀ BẢO TRÌ	10
SỰ CỐ VÀ CÁCH KHẮC PHỤC	11
HÃY BẢO VỆ MÔI TRƯỜNG CỦA BẠN	12

CONTENTS

SAFETY CAUTIONS	15
SPECIFICATION	16
GENERAL DESCRIPTION	17
INSTRUCTION FOR USE	18
APPLICABLE VESSEL	21
CLEANING AND MAINTENANCE	21
TROUBLE SHOOTING	22
ENVIRONMENT FRIENDLY DISPOSAL	23

Tiêu chuẩn kỹ thuật nhà sản xuất có thể thay đổi mà không cần báo trước.

Manufacturer has right to replace technical standard or specification without any notice.

CẢNH BÁO AN TOÀN

Hãy đọc kỹ các hướng dẫn sử dụng trước khi lắp ráp, vận hành và lưu giữ hướng dẫn này cho để tham khảo về sau.

Khi sử dụng thiết bị điện, cần tuân thủ các chú ý an toàn trước khi sử dụng nhằm tránh các rủi ro cháy nổ, điện giật hoặc bị thương như sau:

1. Không để bếp trong môi trường nhiệt độ quá cao. Ví dụ: để bên cạnh bếp ga hoặc bếp dầu.
2. Đặt bếp trên bề mặt phẳng, để cạnh và mặt đáy của bếp cách xa vật thể khác tối thiểu 10cm nhằm tạo không gian để không khí lưu thông thoáng mát vào trong và ra ngoài cho thiết bị.
3. Nếu dây dẫn nguồn bị hỏng thì phải do nhà chế tạo hoặc đại lý dịch vụ hoặc những người có trình độ tương đương thay thế nhằm tránh xảy ra sự cố. Không tự ý sửa chữa, tránh gây tai nạn cho người sử dụng.
4. Vui lòng dùng ổ điện hơn 10A. Không dùng chung ổ điện với thiết bị khác để tránh gây cháy nổ.
5. Không đưa dây sắt hoặc để bất kỳ vật cản nào che đậy các lỗ thoát hơi trong lúc bếp đang hoạt động.
6. Không đặt và vận hành bếp từ trên mặt phẳng bằng kim loại, thảm, khăn trải bàn, tấm giấy mỏng để tránh việc bếp tỏa nhiệt, gây ra nguy hiểm cho người sử dụng và hỏa hoạn.
7. Tuyệt đối không vận hành thiết bị với nồi/chảo rỗng, không có thức ăn bên trong, có thể gây nguy hiểm cho người sử dụng và hỏng hóc cho bếp.
8. Không được đặt bất kỳ vật dụng bằng kim loại nếu đó không phải là nồi hoặc chảo trên mặt kính của bếp trong lúc bếp đang hoạt động.
9. Không được vệ sinh thiết bị bằng nước hay bất kỳ các chất lỏng khác, tránh trường hợp chất lỏng ngấm vào bên trong linh kiện, gây hỏng hóc.
10. Không để các vật liệu dễ bắt lửa tiếp xúc trực tiếp, để gần thân của nồi/chảo và đặc biệt là giữa đáy nồi/chảo và mặt kính của bếp khi đang hoạt động.
11. Luôn rút phích cắm ra khỏi ổ điện sau khi đã sử dụng xong. Khi rút phích cắm, vui lòng cầm nắm ở đầu phích điện để rút ra khỏi ổ. Tuyệt đối không cầm ở phần thân dây để kéo ra khỏi ổ điện, dẫn đến hư hỏng cho thiết bị và nguy cơ giật điện cho người sử dụng.


12. Không để các vật dụng, đặc biệt bằng kim loại như dây sắt, ốc, vít,...lọt vào bên trong thân bếp qua các kẽ hở thoát hơi.
13. Để bếp tránh xa tầm tay của trẻ em. Không được để trẻ em sử dụng bếp.
14. Nếu phát hiện mặt kính của bếp bị nứt, bể, hay có dấu hiệu bị hư tổn bất kỳ nào, lập tức ngưng sử dụng bếp và đem đến trung tâm bảo hành gần nhất để được hỗ trợ.
15. Không được tự ý sửa chữa và thay thế linh kiện trong bếp. Điện áp cao bên trong vỏ thiết bị có thể gây giật điện và nguy hiểm cho người sử dụng.
16. Để bếp tránh xa nơi ẩm ướt và nguồn nhiệt khi đang sử dụng.
17. Không được di chuyển bếp khi còn để nổi ở phía trên.
18. Không chạm vào bề mặt bếp hay lau chùi ngay sau khi sử dụng bếp xong vì mặt bếp sẽ vẫn còn nóng.
19. Cất giữ bếp ở nơi khô ráo, sạch sẽ và thoáng mát, tránh nơi ẩm mốc và nơi nhiều côn trùng, có thể chui vào bên trong bếp.
20. Với người có tiền sử về bệnh tim mạch, xin vui lòng tham khảo ý kiến bác sĩ trước khi sử dụng.
21. Thiết bị này không thích hợp để sử dụng bởi người tàn tật, thiếu năng trí tuệ, hoặc những người không có kinh nghiệm và thiếu hiểu biết (kể cả trẻ em) trừ khi được giám sát hoặc hướng dẫn sử dụng thiết bị bởi người có trách nhiệm về sự an toàn của họ.

ĐẶC TÍNH KỸ THUẬT

Model	Hiệu điện thế	Công suất (W)	Kích thước sản phẩm (mm)	Trọng lượng (kg)
ICB-6628	220-240V ~50/60Hz	1800W	294 x 374 x 41	2.69kg
ICB-6635	220V~50Hz	1800W	320 x 410 x 41	2.89kg

MÔ TẢ TỔNG QUÁT

1 ICB-6628 / ICB-6635




1	Bảng điều khiển
2	Mặt kính thủy tinh
3	Lỗ thông hơi


4	Dây điện
5	Nồi phụ kiện
6	Nắp đáy

1 ICB-6628 / ICB-6635

Bảng Điều Khiển



Bảng Điều Khiển



HƯỚNG DẪN SỬ DỤNG

1 Chú ý trước khi sử dụng

- Đặt nồi với thức ăn ngay giữa mặt kính bếp.
- Cắm dây điện vào ổ cắm phù hợp để dây điện tiếp xúc tốt với ổ cắm.

Ghi Chú:

- Lau bên ngoài nồi sạch sẽ trước khi đặt lên bếp.
- Không đặt nồi rỗng lên bếp để tránh hư nồi hay nguy hiểm gây cháy.



2 Hướng dẫn tắt / mở thiết bị

- Đặt nồi lên giữa mặt bếp.
- Cắm điện, máy sẽ phát ra tiếng “bíp”, máy ở trạng thái sẵn sàng.
- Nhấn nút “TẮT/MỞ” sau đó chọn nút “CÔNG SUẤT” hoặc “NHIỆT ĐỘ” đối với model ICB-6628 chọn nút “CHỨC NĂNG” đối với model ICB-6635.
- Sau khi nấu, nhấn nút “TẮT/MỞ” để tắt bếp, quạt giải nhiệt trong bếp vẫn tiếp tục hoạt động trong 1 phút.
- Sau khi quạt ngừng, rút phích cắm ra khỏi ổ điện.

3 Các chức năng nấu

Model: ICB-6628

Sau khi chọn nút “TẮT/MỞ”, chọn nút “CÔNG SUẤT” để bếp hoạt động.

Nếu muốn thể hiện nhiệt độ thì chọn nút “NHIỆT ĐỘ”

Điều chỉnh công suất /nhiệt độ bằng cách nhấn  hoặc .

Model: ICB-6635

Nấu lẩu

- Chọn chức năng nấu lẩu, bếp sẽ hoạt động ở công suất mặc định. Công suất hiển thị: 1600W.
- Có thể điều chỉnh từ 200W đến 1800W bằng cách nhấn nút “-” hoặc “+”.

Nấu súp

- Chọn chức năng nấu súp, bếp sẽ hoạt động ở công suất cố định 1600W, thời gian nấu mặc định là 1:30 (90 phút).

Nấu nước

- Chọn chức năng đun nước, bếp sẽ hoạt động ở công suất cố định 1800 W, thời gian nấu mặc định là 0:20 (20 phút).

Xào

- Chọn chức năng xào, bếp sẽ hoạt động ở nhiệt độ mặc định. Nhiệt độ hiển thị: 220°C.
- Có thể điều chỉnh từ 60°C đến 240°C bằng cách nhấn nút “-” hoặc “+”.

Chiên

- Chọn chức năng chiên, bếp sẽ hoạt động ở nhiệt độ mặc định. Nhiệt độ hiển thị: 200°C.
- Có thể điều chỉnh từ 60°C đến 240°C bằng cách nhấn nút “-” hoặc “+”.

Hấp

- Chọn chức năng hấp, bếp sẽ hoạt động ở công suất cố định 1800W, thời gian nấu mặc định là 1:00 (60 phút).

Lưu ý

- Điều chỉnh công suất/ nhiệt độ: nhấn nút “-” hoặc “+” để điều chỉnh một mức, nhấn và giữ sẽ điều chỉnh nhanh hơn.
- Đối với ICB-6635 chức năng “Nấu súp”, “Nấu nước” và “Hấp”, bếp hoạt động ở công suất và thời gian cố định, không thể tăng hoặc giảm.

Khóa an toàn cho trẻ em (áp dụng cho ICB-6635)

Khóa an toàn cho trẻ em được thiết kế đặc biệt để ngăn chặn trẻ em không vận hành thiết bị khi không có người giám sát.

Khóa:

Khi bếp đang hoạt động, nhấn và giữ nút “KHÓA AN TOÀN” hơn 3 giây, chức năng khóa bắt đầu hoạt động, đèn biểu thị sáng lên, chức năng nấu đã chọn vẫn tiếp tục hoạt động.

Mở khóa:

Nhấn và giữ nút “KHÓA AN TOÀN” hoặc nút “TẮT/MỞ” hơn 3 giây, chức năng khóa sẽ được hủy.

4 Hướng dẫn cài đặt thời gian

- Áp dụng cho model ICB-6628

- Ở trạng thái sẵn sàng, nhấn “HẸN GIỜ” để cài đặt chế độ hẹn giờ nấu. Nhấn “+” và “-” để tăng/giảm thời gian cần hẹn giờ. Mỗi lần nhấn sẽ điều chỉnh 1 phút, nhấn và giữ sẽ điều chỉnh nhanh hơn.
- Sau khi cài đặt, màn hình hiển thị thời gian sẽ bắt đầu đếm ngược, khi hết thời gian cài đặt, máy sẽ có tiếng bíp thông báo và bếp ngưng hoạt động. Thời gian cài đặt từ 1 phút đến 3 giờ.

- Áp dụng cho model ICB-6635

- Ở trạng thái sẵn sàng, nhấn “HẸN GIỜ” để cài đặt hẹn giờ nấu. Nhấn “+” và “-” để tăng/giảm thời gian cần hẹn giờ. Mỗi lần nhấn sẽ điều chỉnh 1 phút, nhấn và giữ sẽ điều chỉnh nhanh hơn.
- Chức năng “Nấu lẩu”, “Xào”, và “Chiên”, thời gian hẹn giờ từ 1 phút – 3 giờ.
- Chức năng “Nấu súp”, thời gian hẹn giờ từ 4 phút – 1 giờ 30 phút.
- Chức năng “Nấu nước”, thời gian hẹn giờ từ 3 phút – 40 phút.
- Chức năng “Hấp”, thời gian hẹn giờ từ 40 phút – 1 giờ 30 phút.
- Sau khi cài đặt, màn hình hiển thị thời gian sẽ bắt đầu đếm ngược, khi hết thời gian cài đặt, máy sẽ có tiếng bíp thông báo và bếp ngưng hoạt động.
- Hủy bỏ cài đặt: nhấn “HẸN GIỜ”, cài đặt sẽ được hủy bỏ.

CÁC LOẠI NỒI PHÙ HỢP

Chất liệu nôi

- Chất liệu nôi: Nồi/chảo bằng thép, sắt tráng men, thép không gỉ với đáy nôi/chảo phẳng, đường kính đáy từ 12cm đến 26cm.
- Đề nghị sử dụng nôi phụ kiện đi kèm theo bếp hoặc nôi đúng chất liệu nêu trên thay vì sử dụng các loại nôi khác.

Sử dụng nôi theo yêu cầu bên dưới:

- Trọng lượng: trọng lượng nôi bao gồm thức ăn và nước bên trong phải nhỏ hơn 15kg.
- Nôi/chảo phải phù hợp sử dụng cho bếp từ.
- Nôi/chảo khi mua phải thử trước để kiểm tra xem có hiện tượng không bình thường hay không.
- Nôi/chảo khi mua phải có đáy phẳng và đi kèm với nắp có lỗ thoát hơi.



Ghi Chú:

Để đảm bảo an toàn, bạn cần phải đổ nước đầy nôi và nấu sôi để loại bỏ tạp chất trước khi sử dụng lần đầu tiên.

CÁCH VỆ SINH VÀ BẢO TRÌ

1. Tắt điện trước khi vệ sinh bếp. Không lau bếp cho đến khi mặt bếp nguội hẳn.
2. Vệ sinh mặt kính, bảng điều khiển và vỏ ngoài của bếp:
 - Dùng vải mềm cho các vết bẩn nhẹ.
 - Với vết dầu mỡ, bụi, vết mực thì sử dụng vải ẩm với xà bông có chất tẩy nhẹ.
3. Khi quạt đang hoạt động, bụi và chất dơ sẽ bám vào trong lỗ thông hơi, vui lòng vệ sinh bằng bàn chải mềm hay tăm bông cotton thường xuyên.
4. Không vệ sinh bếp bằng cách nhúng trực tiếp vào nước hay chất lỏng khác để tránh nguy hiểm.
5. Để an toàn cho bếp, phải đảm bảo phích cắm tiếp xúc tốt với ổ cắm điện.

6. Không giật dây điện ra khi bếp đang hoạt động. Để tăng tuổi thọ của bếp, nên tắt bếp bằng cách nhấn nút "TẮT/MỞ" trước, sau đó mới rút điện ra.
7. Không nên rút điện ra ngay sau khi nấu xong, vì sau khi tắt bếp, quạt vẫn hoạt động để làm nguội bếp.
8. Vui lòng rút dây điện ra và cất bếp vào nơi khô ráo khi không sử dụng trong một thời gian dài.

SỰ CỐ VÀ CÁCH KHẮC PHỤC

Các trường hợp như bên dưới không có nghĩa là sản phẩm bị hư, vui lòng tự kiểm tra trước khi mang sản phẩm đi sửa chữa.

BIỂU THỊ LỖI	SỰ CỐ	CÁCH KIỂM TRA
E0	Sau khi chọn chức năng nấu, máy liên tục phát ra tiếng "bíp" ngắn.	Kiểm tra đã đặt nôi lên bếp chưa? Vật liệu, kích thước, hình dáng nôi có phù hợp không? Nôi được đặt giữa mặt kính chưa?
E1	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Hiệu điện thế quá thấp không?
E2	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Hiệu điện thế quá cao không?
E3	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Nhiệt độ bếp quá cao, để nguội rồi sử dụng lại. Sau khi để nguội vẫn không hoạt động được, hãy đem máy đi sửa chữa.
E4	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Nhiệt độ bếp quá cao, để nguội rồi sử dụng lại. Sau khi để nguội vẫn không hoạt động được, hãy đem máy đi sửa chữa.

E5	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Nhiệt độ bếp quá cao, để nguội rồi sử dụng lại. Sau khi để nguội vẫn không hoạt động được, hãy đem máy đi sửa chữa.
E6	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Nhiệt độ bếp quá cao, để nguội rồi sử dụng lại. Sau khi để nguội vẫn không hoạt động được, hãy đem máy đi sửa chữa.
E7	Thiết bị ngưng đun nóng đột ngột khi đang sử dụng, máy liên tục phát ra tiếng "bíp" ngắn.	Hư sensor (Cảm biến) nhiệt độ, cần đem máy đi sửa chữa.

Nếu bếp vẫn không hoạt động sau khi tự kiểm tra, phải ngay lập tức liên hệ với các trạm bảo hành gần nhất. Không tự ý tháo lắp sản phẩm, nếu không chúng tôi không chịu trách nhiệm bảo hành.

KHÔNG TỰ Ý SỬA CHỮA THIẾT BỊ

HÃY BẢO VỆ MÔI TRƯỜNG CỦA BẠN



Hãy bảo vệ môi trường của bạn!

Tôn trọng quy định của địa phương: hãy đem những thiết bị điện không sử dụng nữa đến những nơi thu gom phù hợp để tái chế.

BlueStone

User manual Induction Cooker



Apply for models:

ICB-6628

ICB-6635



2
NĂM BẢO HÀNH
YEAR WARRANTY

Always keep manual for your safety

CB

• Standard Compliance

BlueStone products are manufactured under the Standards and the technical rules for product safety design and testing.

BlueStone products and associated accessories intended for professional, industrial process under CE (The European Conformity), EMC (Electromagnetic Compatibility), GS (Geprüfte Sicherheit), CB Standards and have been successfully tested on areas: sampling test, assembling test and lot test.

• Trademark

BlueStone manufactured products are based on the consultation by Great American Appliance (GAA Corp) a company incorporated and existing under the laws of United States of America under Certificate of Incorporation No. 3089043 in the secretary office located in the state of California in Michigan, Ave Oakland, CA 94605, USA.

• Industrial design

Bluestone provides products with industrial design and color variations offering a broad range of possibilities for customers. Through the experienced designers and technicians, Bluestone design has highly reliable solutions so the customers are assured of quality designed systems that meet stringent industry and international compliance regulations.

• After sales service

After sales service is considered by BlueStone as a major concern for our customers. With such, we provide our BlueStone products with a 2 years guaranteed warranty that help our end user feel at ease.

SAFETY CAUTIONS

Please read and understand this entire manual before attempting to assemble, operate or install the product. Make sure to keep this manual in a convenient place to reach for reference later.

When using electrical appliances, basic precaution should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Do not use the unit under high temperature environment, for example, do not use the unit besides the gas and oil stove.
2. Put the unit on the flat surface, please keep the side and back of the unit more than 10cm away from other objects.
3. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid hazard. Do not attempt to disassemble or repair the unit by yourself.
4. Power outlet for this unit should be measure above 10A. To avoid fire hazard please do not use the same outlet with other appliance.
5. Always make sure the ventilation holes are at all times, free of obstruction while the unit is operational.
6. Do not put and operate the unit on metal surface, carpet, table cloth & other flammable object to avoid heat radiation from the unit that could potentially cause fire hazard.
7. Do not operate the unit while the cooking pot/frying pan is empty. Attempting to do so will damage the unit as well as causing injury to the user.
8. Do not place any metal with magnetic trait on top of the unit's cooking surface other than induction cookware while the unit is operational.
9. Do not soak or rinse in water or any other types of liquid to avoid damage to the internal components of the unit.
10. Do not place flammable material/object directly touching the outer surface of the pot/frying pan, especially between the bottom side & the unit's cooking surface while cooking.
11. Always remember to unplug after use. While unplugging the power cord from the outlet, please hold firmly onto the plug and gently pull away from the electrical outlet. Under no circumstances should you unplug by pulling on the cord, damaging the cable and can potentially cause electrical shock.


12. Do not allow any small object, especially metals like iron wire, screw, etc. to fall inside the unit's body through the ventilation holes.
13. Keep the unit away from children's reach. Make sure that children are not in a position to use the unit.
14. Under circumstances that the ceramic surface is found to be cracked or damaged, immediately stop using the unit and bring it to the closest warranty center for repair.
15. Do not attempt to repair or disassemble the unit by yourself. High voltage found within the unit can potentially cause electric shock to the user.
16. Keep the unit away from wet places or near a heat source while operational.
17. Do not move the unit while the cooking pot/frying pan is still on top/during use.
18. Do not touch the ceramic surface on top of the cooking zone or immediately clean with damp cloth right after using.
19. Store the unit away in a clean & dry place, avoiding moist area where insect can potentially damage the unit if they enter inside through the ventilation holes.
20. If the operator is installed with cardiac pacemaker, please follow the doctor's advice before using.
21. For users with a heart condition, kindly seek for doctor advice before using the unit.
22. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SPECIFICATION

Model	Voltage	Power (W)	Product Dimension (mm)	Weight (kg)
ICB-6628	220-240V ~50/60Hz	1800W	294 x 374 x 41	2.69kg
ICB-6635	220V~50Hz	1800W	320 x 410 x 41	2.89kg


GENERAL DESCRIPTION

1 ICB-6628 / ICB-6635



1	Control panel
2	Crystal glass plate
3	Gas vent


4	Power wire
5	Accessory: pot
6	Roof cover

1 ICB-6628 / ICB-6635**Control Panel****Control Panel****INSTRUCTION FOR USE****1 Attention before using**

- Place the pan with food on the center of crystal glass plate.
- Plug in a suitable socket and get good contact.

Notes:

- Clean the water, oil or other dirt on the pan before placing it on the unit.
- Please do not place an empty pot on the unit to avoid the pot getting damaged or the danger of fire.

**2 ON/OFF operation instruction**

- Place the provided pot at the center of the plate.
- Plug in, the buzzer will sound, entering waiting mode.
- Press "TẮT/MỞ" button, choose the function key.
Choose "CÔNG SUẤT" or "NHIỆT ĐỘ" apply model ICB-6628
Choose "CHỨC NĂNG" apply model ICB-6628
- After cooking, press the "TẮT/MỞ" button, enter the shutdown state, fan automatic delay heat for a minute.
- After using, shut off the power.

3 Function selection instruction**Model: ICB-6628**

After select "TẮT/MỞ", select "CÔNG SUẤT". If the user would like to display temperature on the LED, select "NHIỆT ĐỘ".

Adjust the power/ temperature by pressing or .

Model: ICB-6635**Hot pot "Nấu lẩu"**

- Selected hot pot function, hot pot function indicator light, machine default power works. Rating power: 1600W.
- The user can adjust the actual cooking power by touching " - " or " + " button in the 200W-1800W power adjustment range.

Soup "Nấu súp"

- Selected "Nấu súp" function, soup function indicator light, machine default power work. Rating power: 1600W . The set time is 1:30 (90 minutes).

Water "Nấu nước"

- Selected "Nấu nước" function, water function indicator light, machine default power work. Rating power: 1800W. The set time is 0:20 (20 minutes).

Stir-fry "Xào"

- Selected "Xào" function, stir-fry function indicator light, machine default power work. Rating temperature: 2200C.
- The user can adjust the actual cooking temperature by touching " - " or " + " button in the 600C - 2400C temperature adjustment range.

Fry "Chiên"

- Selected "Chiên" function, fry function indicator light, machine default power work. Rating temperature: 2000C.
- The user can adjust the actual cooking temperature by touching " - " or " + " button in the 600C - 2400C temperature adjustment range.

Steam "Hấp"

- Selected "Hấp" function, steam function indicator light, machine default power work. Rating power: 1800W. The set time is 1:00 (60 minutes).

Childlock (apply for ICB-6635)

- Special design of humanistic child safety locks, can follow Induction cooker lock buttons, prevent children unattended tamper with disorderly with unsafe factors happen.
- In the working status, long press "KHÓA AN TOÀN" key more than 3 seconds, can start Child locker function, Child locker function indicator light, Child locker start, the executing function state unchanged.
- Unlock methods: long press "KHÓA AN TOÀN" or "TẮT/MỞ" more than 3 seconds, can cancel Child locker function.

Note:

- Power/ temperature regulation: Single click " - " or " + " key to 1 file for a single unit adjustment, long press can be adjusted quickly.
- For Soup "Nấu súp", Water "Nấu nước", Steam "Hấp" function; the induction cooker cannot be adjusted to increase or decrease the set power and the set time.

4 Timer function instruction

For model ICB-6628

- During standby, press "HẸN GIỜ" then press "+" and "-" to set the desired timer duration.
- Tapping the icon once for minute by minute adjustment, press & hold for faster increase/decrease.
- The cooker will begin to count down while it's operational. At the end of the set timer, the alert sound will alarm and the cooker will stop operating. The timer range is between 1 minute to 3 hours.

For model ICB-6628

- During standby, press "HẸN GIỜ" then press "+" and "-" to set the desired timer duration
- Tapping the icon once for minute by minute adjustment, press & hold for faster increase/decrease.
- For Soup "Nấu súp" function, you can set the timer from 4 minutes to 30 minutes.
- For Water "Nấu nước" function, you can set the timer from 3 minutes to 40 minutes.

- For Steam "Hấp" function, you can set the timer from 40 minutes to 1 hour and 30 minutes.
- The cooker will begin to count down while it's operational. At the end of the set timer, the alert sound will alarm and the cooker will stop operating. The timer range is between 1 minute to 3 hours.
- To cancel timer function, press "HẸN GIỜ" once more

APPLICABLE VESSEL

1 Material required

- Steel, enameled iron, stainless steel, flat-bottom pans/pots with bottom diameter from 12cm to 26cm.
- So suggest to use the required pot, do not try to use other pot instead (especially pressure sensors vessels).

2 Please kindly according to the below requirement

- Weight requirements: the pot (including the food and water inside) is less than 15kg.
- Pan/pot must be suitable for induction cooker.
- Pan/pot should be tried out if it's bought by yourself to see if there are unusual phenomena.
- Pan/pot bought by yourself should be flat and come with the cover with gas vent.



*Noted:

For safety, you must pour water full of pot and boil to reject impurities before first use.

CLEANING AND MAINTENANCE

1. Remove the power plug prior to cleaning the unit. Do not clean it until the cooking surface has completely cool down.
2. To clean the ceramic surface, control panel an the outer layer of the unit
 - * Use soft cloth to wipe away slight stain.
 - * Use a damp cloth with light detergent for grease, dirt or ink blot.

3. While the radiator fan working, dust and dirt would remain on the gas vent, please clean it by brush or cotton stick regularly.
4. Remember do not wash the unit by water directly to avoid damaging.
5. To protect induction cooker, be sure to have a good contact between plug and socket before using.
6. Do not pull out the power cord directly during operation. To extend the appliance's using life, press "TẮT/MỞ" button first, then pull out the power cord.
7. The fan would still working for cooling the plate. In order to make operating time longer, it is better to plug out after the fan stops working.
8. Please pull out the power cord and put it away when not used for a long time.

TROUBLE SHOOTING

The cases below do not mean the unit breaks down, please kindly check by yourself before sending to repair.

FAULT DISPLAY	POSSIBLE REASON	SOLUTION
E0	After starting up, the machine of continuous send a short "beep".	If there is a pot? Pot material, size, and shape are right? Pot is placed in the middle of the microcrystal panel?
E1	Use of a sudden stop heating, the machine continuously send a short "beep".	The voltage is too low?
E2	Use of a sudden stop heating, the machine continuously send a short "beep".	The voltage is too high?
E3	Use of a sudden stop heating, the machine continuously send a short "beep".	The temperature of the cooker is too high, after cooling to use. If the cooker is not used, please contact after-sales service.

E4	Use of a sudden stop heating, the machine continuously send a short "beep".	The temperature of the cooker is too high, after cooling to use. If the cooker is not used, please contact after-sales service.
E5	Use of a sudden stop heating, the machine continuously send a short "beep".	The temperature of the cooker is too high, after cooling to use. If the cooker is not used, please contact after-sales service.
E6	Use of a sudden stop heating, the machine continuously send a short "beep".	The temperature of the cooker is too high, after cooling to use. If the cooker is not used, please contact after-sales service.
E7	Use of a sudden stop heating, the machine continuously send a short "beep".	The sensor of plate surface failed protection, please contact after-sales service.

If it is still not working after the inspection by yourself, please immediately contact our service points, do not apart the unit by yourself or our company is out of responsibility.

Be sure to use the power cord recommended by the appliance manufacturer after it is damaged.

DO NOT TRY TO ADJUST OR REPAIR THIS APPLIANCE BY YOURSELF

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.

